


5. PRACTICAL OPERATION

5-1 SCANNING

A) Frequency indication method



1. Push the scan key
The decimal point flashes and scanning begins.
2. During scanning, rotate the channel control clockwise to increase the displayed channel number and scanning proceeds in a positive direction; rotate the channel control counterclockwise to decrease the displayed channel number and scanning proceeds in a negative direction.

3. Push the SCAN during scanning to stop scanning.


(Scan operation)

When a signal is received, scan pauses for 5 secs. then resumes again. If the signal disappears before 5 secs. elapses, the scan resumes at that point.

Both the LAMP key and MONI key can be used during scanning.

NOTE: If scanning is not performed with the SCAN key while the radio is not key-locked (KL), the operation has been disallowed by your Dealer.

B) Channel indication method



c 000
c

c 100
c

c 120
c

c 123
c

c 423
c

⋮
ch-9
c

c 000
c

Confirmation and setting your own station code

Your own code is made up of a 3-digit number. Follow the procedure below to set a desired code.

1. When C is displayed: while pushing F, push the code key.
The current code is displayed.

2. Use the keyboard to enter the desired code (starting from the 1st digit). Entering more than 3 digits will overwrite previously entered digits.

NOTE: Only numeral keys may be entered.

Push the ANS key or PTT to return to the initial display.

To clear a code during input or for the exiting code: while pushing F, push C.