


# Wireless Camera Scanner (Palm type) Manual


## ➤ Instruction Drawing



## ➤ Specification

ISM Band	900MHz ~ 2520MHz
Switcher	Auto/Manual
Antenna	SMA
Battery Working Time	3Hrs approx. (Depend monitor on)
Power Input	DC 5V , 650mA(MAX) or AA Battery DC 1.5V x4
Video Display	2.5" Color TFT Monitor
Frequency Display	LCM
Auto Scan	20 sec/Per Cycle(H)-10 sec/Per Cycle(MH,M,ML,L)
Manual Scan	Once:1MHz/sec , Fastforward:10MHz/sec
Dimension	120(L) x 74(W) x 35(H)mm
Weight	240g

## ➤ Dimensions



## ➤ Assembly Order

- (1) Assembly SMA antenna to scanner first.(Left H , Right L)
- (2) Connect the power with the adaptor or insert four units AA size batteries by matching.(4XAA alkaline batteries.Alkaline battery life 3 hour approximately (not included))

## ➤ How to operate

- (1) Function adjust
  - a. After the power switch to ON , to press smartkey to 3sec later and then unlock.
  - b. Option function and to use smart key upper and lower fine tuning.(To adjust when the icon blinking.)
  - c. To press smartkey to 3sec can finish all settlement.

📷	Capture moving picture	🏠	Sensitivity icon	📢	Warning indicator
2	2 sec	L	-20dBm	ON	OPEN ☉
		ML	-30dBm		
4	4 sec ☉	M	-40dBm	OFF	CLOSE
		MH	-50dBm		
8	8 sec	H	-60dBm ☉		

☉ Establish in advance 📷 The remaining battery indicator 📢 Sensitivity indicator

## ➤ Warning

### AC Power adaptor

1. Unplug the unit from the wall outlet when you are not using it for a long time. To disconnect the power cord, Pull it out by the plug. Never pull the power itself.
2. Do not bend the power cord forcibly, or place a heavy object on it. This will damage the cord and may cause fire or electric shock.
3. While the unit is in use, particularly during charging, keep it away from AM receivers and video equipment. AM receivers and video equipment disturb AM reception and video operation.

### Battery

1. To prevent accident from a short circuit, do not allow metal objects to come into contact with the battery terminals.
2. Never expose the battery pack to temperatures above 60°C (140°F), such as in a car parked in the sun or under direct sunlight.
3. Keep the battery cell dry.

- (2) When scan the video signal, push the smart key to lock.

### Wireless CameraScanner Include:

- (1) CameraScanner ..... 1pcs
- (2) SMA Antenna..... 2pcs
- (3) Adaptor (DC5V)..... 1 pcs
- (4) Alarm Terminal..... 1pcs
- (5) Instruction manual..... 1 copy

### Important:

Users and installers of product are responsible for ensuring this product complies with all national, state, and local laws and statutes related to monitoring and recording video signals.

