



(4) Answerback




"A" appears

"C" indicator



"A" disappears



"A" indicator

At the same time the display is showing the receive information, the operations below are being carried out.


When a personal call has been received while "A" is indicated in the LCD, and answer will be automatically sent back. The method of answering back is set by your Dealer.

1. The transceiver's own code is sent as an answer back
2. The condition code is sent as an answer back
3. A single tone is sent as an answer back


When "A" is not indicated, or when receiving a group call, an answer back will not be sent, and the radio will beep for 10 secs. Beeping stops upon subsequent operation.

When no operation is carried out, or no signal is received for 10 secs., the squelch returns to its previous condition.

Turning answerback ON/OFF



ANS




When permitted by the dealer, answerback can be turned ON and OFF.

If after turning the power ON, "A" and "D" appear, push the ANS key.

"A" disappears, and the answer back function is turned OFF. Push the ANS key again and "A" appears once more.

NOTE: If, after turning the power ON, "A" and "D" do not appear, your Dealer has disabled turning answerback ON and OFF. In this case, pushing the ANS key will have no effect.

6-2-3 DTMF cancel mode




When neither "C", "A", or "D" is displayed, the transceiver is in DTMF squelch cancel mode. Although received codes cannot be checked for agreement, transmit is possible.

Transmit method

While pushing the PTT, numeral codes are transmitted as pushed in real time.

Auto-dialling and redialling are also possible.



⑤ **LCD (liquid crystal display)** Displays all active functions.

⑥ **Function key**

Push and hold this key to activate the secondary functions of other keys.

⑦ **PTT key**

Push and hold to transmit; release to receive.

⑧ **Battery release**

Used to change the battery case. Push and hold this knob upwards, then slide the battery case free of the transceiver.

⑨ **Speaker**

Built-in speaker.

⑩ **Microphone**

Built-in condenser-microphone.